


1ST Starts™

Kick Start Busy Crib Center™


Includes 3 "AA" batteries. Phillips screwdriver (not included) needed for battery replacement.



PLAYSKOOL®



TO ATTACH TOY TO CRIB



1. Position toy inside crib near top rail.
2. Wrap strap around top crib rail, and fit strap hole onto raised tab on toy.
(For easiest attachment, fit strap hole onto one side of tab, then the other side.) Repeat process for other strap. Be sure toy is attached snugly to crib. Also, check to ensure that top of raised tab is fully through strap hole, and that strap is not twisted.
3. Wrap lower strings around outside of crib bar and tie them into a secure knot.

Caution: To avoid head entrapment:

Make sure lower strings are properly secured.

PLAY FEATURES

- The KICK START BUSY CRIB™ Center has 2 electronic modes to choose from - active and soothe. Select the mode you want by moving the switch on the back of the toy.



ACTIVE MODE

In this mode, baby can kick or press the kick panel to activate a lively burst of music, fun sounds, blinking, light-up birds and a rattling roller with swirling beads.

Note: After 30 seconds of inactivity in the active mode, the toy will briefly light and sound to prompt baby. Then, it will "go to sleep," turning on again when baby kicks or presses the kick panel or presses the birds.

SOOTHE MODE

In this mode, songs play for a longer duration than in active mode, with an overall playing time of 10 minutes. During this time, the light-up birds will softly blink in time to the music. Pressing the kick panel or birds while a song is playing causes it to skip to the next song and to play for an additional 10 minutes.

Note: If the toy is left untouched, the soothe mode will last for approximately 10 minutes, after which the toy will "go to sleep." The toy turns on again when baby kicks the kick panel or presses the birds.

Turn the switch to OFF to deactivate the electronic lights and sounds. 

• Song List:

ACTIVE MODE:

Rockin' Robin

Polly Wolly Doodle

Sing a Song of Sixpence

Alouette

Be My Little Bumblebee

SOOTHE MODE:

Frere Jacques


Spring (Vivaldi)


Brahm's Lullaby

Minuet

Beautiful Dreamer

Twinkle, Twinkle Little Star





Use a Phillips screwdriver (not included) to loosen screw in battery compartment door (screw remains attached to door). Remove door. Insert 3 fresh "AA" alkaline batteries (not included). Replace door and tighten screw.

CAUTION: TO AVOID BATTERY LEAKAGE

- 1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;**
- 2. Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;**
- 3. Always remove weak or dead batteries from the product.**

FCC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help."

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Product and colors may vary.

© 2000 Hasbro, Inc. All Rights Reserved.

® denotes Reg. U.S. Pat. & TM Office.

U.S. Patent Pending.

P/N 4903580100