### IMPORTANT: BATTERY INFORMATION

## **CAUTION:**

- 1. Always follow the instructions carefully. Use only batteries specified and be sure to insert them correctly by matching the + and polarity markings.
- 2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
- 3. Remove exhausted or dead batteries from the product.
- 4. Remove batteries if product is not to be played with for a long time.
- 5. Do not short-circuit the supply terminals.
- 6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
- 7. RECHARGEABLE BATTERIES: Do not mix these with any other types of batteries. Always remove from the product before recharging. Recharge batteries under adult supervision. DO NOT RECHARGE OTHER TYPES OF BATTERIES.



 $\triangle$  Caution:


Do not aim at eyes or face. TO AVOID INJURY: Use only darts designed for this product. Do not modify darts or dart blaster.

AGES 6+



# BARRICADE RV-10T

Be sure to read and follow all instructions carefully before using this product.



Hasbro

© 2010 Hasbro. All Rights Reserved. TM & ® denote U.S. Trademarks. Patent Pending. 186160900 PN 7077180000



Not suitable for children under 3 years because of small parts - choking hazard.

Product and colors may vary.

NERF.COM
FOR NEW PRODUCTS AND OFFERS

Questions? Call: 1-800-327-8264


1.5VAA or LR6 size NOT INCLUDED REQUIRED

Phillips/cross head screwdriver (not included)

NOTE: JAM CLEARING DOOR must be fully closed for blaster to fire. READY INDICATOR must be green for blaster to fire.




#### TO INSERT BATTERIES




- Loosen screws in battery compartment door with a Phillips/cross head screwdriver (not included).
- Remove battery door. Insert 3 x 1.5V "AA" or LR6 alkaline balteries.
- Replace battery door and tighten screws.

#### LOADING AMMO

**(** 





 Be sure the blaster is turned off before loading DARTS.



Rotate the barrel by hand to access dart tubes. Insert darts completely into barrel.

#### FIRING






**1** Slide switch to "ON" position.

Pull trigger all the way to fire.


NOTE: JAM CLEARING DOOR must be fully closed for blaster to fire. READY INDICATOR must be green for blaster to fire.

#### **CLEARING A JAM**


#### If blaster appears jammed:



**Move POWER SWITCH to "OFF."** 



Open JAM CLEARING DOOR and remove any jammed darts. Close door.



NOTE: Blaster will not function unless JAM **CLEARING DOOR is fully closed. READY** INDICATOR should be green for blaster to fire.