

**PLAYSKOOL**  
baby toys


# Attach 'n Go™ Adapter for Aprica® Strollers

This adapter modifies all Aprica® Strollers for use with Playskool's Attach 'n Go Stroller Play Center and Attach 'n Go Driver.

## HOW TO ASSEMBLE:

**NOTE:** Your Attach 'n Go will replace the Aprica® padded cross-bar.

1. To remove the Aprica® padded cross-bar, push up on the bottom of the T-pin. Completely remove both the T-pin and the Slide Mount. End of padded cross-bar may now be detached.
2. Fit the notched end of the Attach 'n Go Adapter into the Slide Mount's open area. (This will change position of Slide Mount when replaced in Arm Rest.)
3. Position the Slide Mount and Adapter assembly into the Arm Rest, as shown.
4. Push the T-pin back into the Arm Rest until it snaps into place.
5. Repeat procedure for the other side.
6. Adjust and tighten Attach 'n Go clamps to protruding Adapter as described for other stroller brands.



Playskool Baby Toys  
for fun...for learning...to keep and to love.



7860089100

PLAYSKOOL, INC., A Milton Bradley Company Chicago, IL  
© 1984 Playskool, Inc. Under Berne & Universal Copyright C  
MADE IN U.S.A.

