


REMOTE CONTROL BATMOBILE®

ASSEMBLY REQUIRED.

BATTERY REQUIREMENTS / INSTALLATION FOR VEHICLE



1 Remove screw. Remove battery door from bottom of vehicle as shown.


2 Install 4 "AA" Alkaline Batteries as shown. Replace door. Replace screw.

NOTE:


- Vehicle power switch must be ON to play.
- Always slide vehicle power switch OFF after play. Vehicle lights up only when in motion.

CONTROLLER INSTRUCTIONS

DIRECTION CONTROLS



FORWARD



BACKWARD AND TURN

WARNING:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

SAFETY PRECAUTIONS:

This vehicle is not recommended for children under the age of 4 years. Please read all of the instructions before operating this vehicle. Always follow general safety rules while operating vehicle: avoid hitting pets, furniture or people. Do not pick-up vehicle while it is in motion. Keep hands, hair and clothing away from this vehicle when using the controller and wheels of car are in motion. Remove batteries when vehicle is stored. **Avoid tire contact on painted or varnished surfaces.** Recommended outdoor play with this vehicle.

CAUTION:

TO AVOID BATTERY LEAKAGE

- 1) Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
- 2) Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable batteries.
- 3) Always remove exhausted or dead batteries from the product.

PROPER OPERATION AND STORAGE OF YOUR VEHICLE

1. **Best operation** of vehicle is on an OUT-OF-DOORS textured paved surface to avoid furniture damage and minimize noise level.
2. **Always** operate your vehicle on dry surfaces away from cars and other full-size vehicles.
3. **Always** store your vehicle in a cool, dry place and off of painted or varnished surfaces.
4. **Avoid** water or damp locations which may damage the vehicle's electronics. (If your vehicle ACCIDENTALLY gets wet and stops running, let it dry overnight before trying to run it again.)



BATMAN, ROBIN and all related characters, names and indicia are trademarks of DC Comics © 1997.
KENNER® is a trademark of Hasbro, Inc. ©1997 Hasbro, Inc.
All Rights Reserved.
© denotes Reg. U.S. Pat. & TM Office.

27826

MADE IN CHINA.

P/N 47281100