



Huff 'n Puff Vacuum™

Instructions


Thank you for buying this Playskool® product!

Includes: Vacuum with clear top dome, flexible hose, hose attachment, and 36 fabric play pieces. 4 "D" batteries and a Phillips screwdriver are needed for battery placement (not included).

NOTE TO PARENTS

BEFORE GIVING TOY TO YOUR CHILD:

Remove the wire ties that hold the vacuum and accessories in place for retail display. Discard the ties immediately, before giving toy to your child.





AFTER PLAY:

1. When your child is finished playing, the play pieces can be stored in the top dome. The hose can be placed into the holder on vacuum as shown, by fitting the tab on bottom of hose attachment into hole in front of switch on vacuum.

IMPORTANT

NOTE TO PARENTS:

The Huff 'n Puff Vacuum is specifically designed to pick up the play pieces included, and designed not to pick up larger or heavier objects that could be harmful to your child. If any of the play pieces are lost during play, you can make more by cutting 1" circles from newspaper or tissue paper using a pair of scissors as shown.



© 1996 Hasbro, Inc., Pawtucket, RI 02862 USA. All Rights Reserved.

® denotes Reg. U.S. Pat. & TM Office.

U.S. Patent Pending.

ASSEMBLED IN MEXICO FROM U.S. & CHINESE COMPONENTS.


775

P/N 47190700



AGES
3 & UP
PRESCHOOL

BATTERY PLACEMENT:




1. The battery compartment is located on the bottom of the vacuum. Use a Phillips screwdriver to remove the 2 screws that secure the battery door, and remove door.
2. Insert 4 "D" batteries (alkaline recommended) into the battery compartment as shown. Replace door and secure it in place with the 2 screws.

CAUTION: TO AVOID BATTERY LEAKAGE:



1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions.
2. Never mix old batteries and new batteries, or alkaline, standard (carbon-zinc) or rechargeable batteries.
3. Always remove exhausted or dead batteries from the product.

HOSE ASSEMBLY:




1. Assemble the hose attachment to either end of vacuum hose as shown. For a secure fit, push attachment into end of hose as far as it will go.

2. Attach the other end of hose to the vacuum as shown. For a secure fit, press hose over fitting as far as you can.



PLAY INSTRUCTIONS: The Huff 'n Puff Vacuum has two play modes:



- **HUFF!** Push the switch to the left, and the Huff 'n Puff Vacuum will pick up play pieces and blow them around the clear top dome!
- **PUFF!** Turn the top dome to the "out" position and push the switch to the right, and the Huff 'n Puff Vacuum will blow the play pieces back out of the dome!
- The center of switch is the "OFF" position.

1. The clear top dome has two positions that correspond to the two play modes. When the vacuum is in pick-up mode, the opening in the side of the dome should cover the air hole that the pieces come in through.

2. To put the vacuum in PUFF/blow-out mode, turn the dome counter-clockwise so that the opening is facing out the side of the vacuum as shown. The side of the dome has "stops" that lock the two different positions into place. The dome is also removable when necessary.

3. To pick up play pieces, turn dome back to original position. Throw any or all of the 36 play pieces onto a floor, rug or low-pile carpeting. Pick up the play pieces with a "HUFF!", and blow them back out with a "PUFF!"