

PLAYSKOOL®




# TRACKING THE "T-REX"™

THANK YOU FOR BUYING THIS PLAYSKOOL PRODUCT!

INCLUDES "T-REX," FIGURE,  
VEHICLE AND LAUNCHING CAPTURE NET.

ADULT ASSEMBLY REQUIRED. REQUIRES 2 "AAA" ALKALINE BATTERIES (NOT INCLUDED). PHILLIPS SCREWDRIVER (NOT INCLUDED) REQUIRED FOR BATTERY PLACEMENT.



• YOUR FIGURE CAN RIDE IN THE CAB OF THE VEHICLE, OR ON THE VEHICLE'S SIDE, AS SHOWN!



## FCC STATEMENT:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

## A Note to Parents:

The Jurassic Park films are rated PG-13. Consult [www.filmratings.com](http://www.filmratings.com) for further information. Jurassic Park Junior is a trademark and copyright of Universal Studios and Amblin Entertainment, Inc. Licensed by Universal Studios Licensing, Inc. All Rights Reserved.


©, TM & © 2000 Hasbro, Inc. All Rights Reserved.

® denotes Reg. U.S. Pat. & TM Office.

2031

P/N 6011860000

## TO INSERT BATTERIES IN T-REX




**USE A PHILLIPS SCREWDRIVER TO LOOSEN SCREW IN BATTERY COMPARTMENT DOOR (SCREW REMAINS ATTACHED TO DOOR). REMOVE DOOR. INSERT 2 "AAA" ALKALINE BATTERIES. REPLACE DOOR AND TIGHTEN SCREW.**


## CAUTION:

- 1) As with all small batteries, the batteries used with this toy should be kept away from small children who still put things in their mouths. If they are swallowed, promptly see a doctor and have the doctor phone (202) 625-3333 collect.
- 2) Make sure the batteries are inserted correctly and follow the toy and battery manufacturers' instructions.
- 3) Do not mix old and new batteries, alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.

## TO ASSEMBLE




- SNAP HIND LEGS ONTO T-REX BODY.




- SNAP VEHICLE HALVES TOGETHER.

## TO PLAY



- YOUR T-REX CAN ROAR! JUST PUSH AN ARM DOWN AND THE DINOSAUR'S MOUTH OPENS FOR A REALISTIC ROARING SOUND!



- LAUNCH THE DINO CAPTURE NET! INSERT POSTS ON EACH BARREL INTO THE HOLES IN THE LAUNCHER. PRESS THE LAUNCHER BUTTON TO FIRE THE NET AND CAPTURE THE T-REX! FOR ON-THE-GO ACTION, LAUNCH THE CAPTURE NET FROM THE BACK OF THE VEHICLE! SIMPLY INSERT TAB ON LAUNCHER INTO SLOT ON TRUCK, THEN PUSH LAUNCHER DOWN TO FIT IN PLACE.