Magic Pizza Delivery Instructions




Ages 3 & Up


Thank you for purchasing the Playskool Magic Pizza Delivery! Please save this instruction sheet for future reference. If you have questions, comments or concerns about this product, please call Playskool toll-free at 1-800-PLAYSKL.

Remove all pieces from plastic bags, then discard bags immediately. Requires 2 "AA" batteries (alkaline recommended). Phillips screwdriver needed for battery placement (not included). Includes: Pizza oven, ice tray, ice tray cover, telephone, pizza pan, 4 slices of color-change pizza, spatula, pizza cutter, pizza box, 4 "pepperoni" pieces, 4 "anchovy (fish)" pieces, 4 "mushroom" pieces and instructions.

Inserting The Batteries



The battery compartment is located on the bottom of the pizza oven. Use a Phillips screwdriver to loosen (but not remove) the screw that secures the battery compartment door, and remove door.




Insert 2 "AA" batteries into the compartment, following direction indicators inside compartment. Replace door and re-fasten with the screwdriver.

CAUTION: TO AVOID BATTERY LEAKAGE


- 1. Be sure to insert the batteries correctly and follow the toy and battery manufacturer's instructions.
- 2. Do not mix old and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries.
- 3. Always remove exhausted or dead batteries from the product.
- 4. Remove batteries if product is stored for a long period of time.

NOTE TO PARENTS: Please hand wash all individual play pieces in a solution of mild dishwashing liquid and warm water before using.


Adult Assembly and Preparation




1. With opening for oven door facing front, assemble oven top to oven base as shown, snapping all 6 tabs into fittings on base. Press down a second time on 2 front corner tabs and 2 back corner tabs to make sure top is fully engaged in fittings.




2. Assemble the oven door as shown, slipping tabs on door, one side at a time, into slots on oven.




3. The package insert for this product is also a pizza box! To make the box, simply fold insert as indicated by arrows in illustration. Fold the 4 flaps inside the side walls, then slip the side wall tabs inside the cut-out slots. Fold top over to complete the box.



4. Place the accessories in their respective areas: the spatula and pizza cutter in the left-side slots, the telephone in the top right corner, and the pretend pizza toppings - mushrooms, pepperoni and anchovies — in the 3 right-side slots as indicated by the picture labels.




5. Fill ice tray with ice cubes, and fit ice tray into its place on top of oven. (The ice tray is marked with a "fill line" on the inside. Stack the ice up to, but not above, this line.)




6. Place the lid on top of ice tray, and turn clockwise to lock the lid in place. Now your child is ready to make and "bake" pretend pizzas!


Play Instructions




1. Press the "telephone" button to hear a telephone ringing sound. Pick up the receiver and use one of the "order cards" (cut out from the package) to pretend to take a pizza order!



2. Take the 4 color-change pizza slices and place them in the pizza pan. Then add the pizza toppings in any combination you like!



3. Place the pizza inside the oven and close the oven door. Press the "timer" button and wait for the timer to tick off (approximately 20 seconds).



4. Take the pizza out of the oven, and it's magically changed color to look like it's baked inside the oven! Use the pizza cutter to pretend to slice the pizza, then put the pizza inside the box for delivery!

CHANGING COLOR BACK (FOR PARENTS:)

1. To start the play all over again, run warm water over the pizza slices, and they will return to their original, "unbaked" color. The pizza slices will also gradually go back to their original color as they return to room temperature, or you can rub the pizza slices with your hands, and the warmth of your hands will restore the original color.



© 1995 Hasbro, Inc., Pawtucket, RI 02862 USA. All Rights Reserved. ® denotes Reg. U.S. Pat. & TM Office.

P/N 46050702 MADE IN CHINA c-060A U.S. Patent Pending.