



AGES
3 & UP

SPRAY 'N GO FIRE TRUCK™

2 TOYS IN 1!
Fire Truck
& Sprinkler!


Adult Supervision Required.

CAUTION: Water that is left inside the Fire Truck or garden hose for an extended period of time in direct sunlight can become very hot. Therefore, we recommend draining both and storing them in a cool, shady area when not in use.




1.

Peel and apply labels as shown. Recessed area on right-side label aligns with hose placement.




2.

Fit the end of a standard garden hose into the Fire Truck's hose connector. Turn the hose connector counterclockwise to tighten it over the garden hose.




3.

The control knob at back of vehicle changes water flow from sprinkler to hose. For spinning sprinkler action, turn control knob all the way to the left (counterclockwise) so that the arrow is pointing straight up.




4.

To squirt water from the fire hose, turn control knob all the way to the right (clockwise) so that the arrow is pointing to the right.



5.

Turn the fire hose nozzle clockwise to adjust the water spray. Turn the nozzle counterclockwise to decrease the flow of water.



6.

The hose can be stored on the Fire Truck as shown.

Tonka®

HOW CAN WE HELP YOU?
For More About This And Other
Tonka Products, Call 1-800-24TONKA.

Product and colors may vary.
©1996 HASBRO, INC. Pawtucket, Rhode Island 02860
All Rights Reserved.
ASSEMBLED IN MEXICO FROM U.S.
AND MEXICAN COMPONENTS. 90214 P/N 46963400