


VIDEONow™

Light

Thank you for purchasing the VIDEONow light! Designed with style to match your VIDEONow Player, now you can watch many of your favorite shows – in the dark!


Be sure to read and follow all instructions carefully before using this product.

Requires 1 x 1.5V "AA"/LR6 alkaline battery (not included).
Phillips/cross head screwdriver (not included) needed to insert batteries.



TO INSERT BATTERIES

Using a Phillips/cross head screwdriver, loosen the screw in the battery compartment cover (screw stays attached to cover). Remove cover. Insert 1 x 1.5V "AA"/LR6 alkaline battery. Replace cover and tighten screw.



! CAUTION: TO AVOID BATTERY LEAKAGE

1. Be sure to insert the batteries correctly and always follow the toy and battery manufacturers' instructions;
2. Do not mix old batteries and new batteries or alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries;
3. Always remove weak or dead batteries from the product.

IMPORTANT: BATTERY INFORMATION

Please retain this information for future reference.


Batteries should be replaced by an adult.

! CAUTION:

1. Always follow the instructions carefully. Use only batteries specified and be sure to insert item correctly by matching the + and – polarity markings.
2. Do not mix old batteries and new batteries or standard (carbon-zinc) with alkaline batteries.
3. Remove exhausted or dead batteries from the product.
4. Remove batteries if product is not to be played with for a long time.
5. Do not short circuit the supply terminals.
6. Should this product cause, or be affected by, local electrical interference, move it away from other electrical equipment. Reset (switching off and back on again or removing and re-inserting batteries) if necessary.
7. **RECHARGEABLE BATTERIES:** Do not mix these with any other types of battery. Always remove from the product before recharging. Recharge batteries under adult supervision. **DO NOT RECHARGE OTHER TYPES OF BATTERIES.**

TO USE

1. Slide light unit onto top of player.




2. Slide ON/OFF Switch to the left to turn light on.



ON/OFF Switch

3. Adjust the height of the light to your liking, by gently folding the light unit up or down.



4. Slide ON/OFF Switch to the right to turn light off.
5. Slide light unit off top of player when finished.



© 2003 Hasbro. All Rights Reserved.
® denotes Reg. U.S. Pat. & TM Office.
66715 P/N 6265960000

TIGER[®]
ELECTRONICS

Where Technology Comes to Play!™



Questions? Call: 1-800-327-8264