

598
8-36 mos. Playset
1-3 yrs. Ride-on



Weeables® Busy Playhouse™ Ride-on

Instructions

A Pretty Playhouse and Ride-on... in One!

ASSEMBLY


NO TOOLS REQUIRED.
PARENTAL SUPERVISION REQUIRED.

WARNING: THIS RIDE-ON TOY IS NOT TO BE USED NEAR SWIMMING POOLS, ON OR NEAR HILLS, ROADWAYS, OR STAIRWAYS. SHOES MUST BE WORN AT ALL TIMES WHEN RIDING THIS TOY. DESIGNED FOR ONLY ONE RIDER AT A TIME.


INCLUDES swing, buggy, 2 sets of wheels, rear door, 3 shapes, Baby Weeble, Mommy Weeble and label sheet.




Questions? Call:
1-800-PLAYSKL



Fit top tab on door into top hole in door opening. Slide bottom tab on door into ring at bottom of door opening as shown.






Snap wheels onto buggy as shown.



Open seat and snap posts on swing into holes on underside of seat as shown.


4. Peel and apply labels as shown.




PLAY FEATURES

PRESS the horn for a SQUEAK.

DROP the Weebles down the chute.



OPEN the ride-on seat to find a Weebles playground (on the underside of the seat), and a kitchen and bedroom area (inside the ride-on). Give Weeble rides on the attachable swing, let them glide down the slide, or place them anywhere inside the ride-on!



CLOSE the seat and the toy becomes a foot-to-floor ride-on!

FIT the 3 shapes through the shape sorter holes.

ROLL the buggy with Baby Weeble inside.