



Furby 2012 Sıkça Sorulan Sorular

How do I turn Furby On/Off?

Similar to previous Furbys, Furby Boom does not have an on/off switch. To make Furby fall asleep, try the following:

- Pull tail for 10 seconds
- Place Furby on its back for 15 seconds
- Place Furby in quiet room and do not play with it.
- Remove the batteries.

How do I install the batteries?

1. Loosen 2 screws using a phillips or flat head screwdriver from the plastic base of Furby
2. Remove the base
3. Insert 4 AA alkaline batteries, Duracell recommended
4. Replace base and tighten screws

Where can I find the datecode on my Furby?

Furbys date code is in the form of a hot stamp. It is located inside the battery compartment, visible from the rear closest to the tail.

There is a high pitched tone coming from Furby and/or my iOS device.

The noise you are hearing is how Furby communicates with the mobile device and other Furbys. Some people may hear it, others will not. Some animals may also hear the noise. Don't worry, the tone will not cause any harm to people or animals.

I changed the batteries in my Furby to fresh/new alkaline batteries and it is still acting "weird". How do I fix it?

Remove the base of Furby and push the refresh button for 2 seconds, then replace the base. This will reset the hardware while retaining all of the personality data.

My Furby fell asleep and I can't seem to wake him up.

Remove the base of Furby and push the refresh button for 2 seconds, then replace the base. This will reset the hardware while retaining all of the personality data.

Where are Furby's Sensors?

Furby is sensitive to touch, motion, sound, & other Furbys.

