





BATMAN
BEYOND.


AGES 4 & UP
AGE: 4+
EDAD: 4+



Operation
Fonctionnement
Funcionamiento




UNDERSIDE
DESSOUS
DEBAJO




UNDERSIDE
DESSOUS
DEBAJO

Labels
Autocollants
Etiquetas


ANYWHERE
N'IMPORTE OÙ
EN CUALQUIER PARTE




UNDERSIDE
DESSOUS
DEBAJO




HOW TO LOAD AND FIRE DISCS
POUR CHARGER ET LANÇER LES DISQUES
PARA CARGAR Y LANZAR LOS DISCOS




1
PULL UP AND TURN OUT OF SLOT
RELEVER ET TOURNER POUR SORTIR DE LA FENTE
LEVANTALO Y GIRALO PARA SACARLO DE LA RANURA



2
LOAD DISCS
CHARGE LES DISQUES
CARGA LOS DISCOS




3
TURN AND RETURN TO SLOT
TOURNER POUR RETOURNER À LA FENTE
GIRALO PARA REGRESARLO A LA RANURA



3
FIRE
TIRE
DISPARA

Assembly
Assemblage
Armado

SLOT SIDE UP
CÔTÉ FENTE VERS LE HAUT
LADO DE LA RANURA HACIA ARRIBA



TM & © 1999 Hasbro Canada Inc.,
P.O. Box / C.P. 267, Station / Succ. A,
Longueuil, Québec J4H 3X6
TM & © 1999 HASBRO, INC.
Pawtucket, Rhode Island 02862. All Rights Reserved.

Dist.: Hasbro de México, S.A. de C.V. Pariférico Sur
Nº 4124, 7º piso, Col. Jardines del Pedregal, Del.
Villa Avaro Obregon, Mexico, D.F., C.P. 07900.
Centro de Servicio para México: Calle Venado
Nº 163, Col. La Turba, Del. Tlanahuac, México, D.F.,
C.P. 13300. TEL.: 5645-1362 y 01-800-712-6225.

TM & © 1999 Warner Bros.
BATMAN and related characters, names and
logos are trademarks of DC Comics. © 1999
MADE IN MEXICO
FABRIQUE AU MEXIQUE
HECHO EN MEXICO

559619 0100