


60475

Manta Ray

FIRING TIP : To fire the darts on one side only, apply pressure to



the side of the trigger with a bump as you squeeze the trigger halfway.