




GAME INCLUDES: 1 battle arena, 2 tops, 16 Pokémon character disks (stored in the bottom of the unit)

Which Pokémon is stronger? With Tiger's electronic Pokémon Challenge, you can find out!



INSERTING THE BATTERIES

Using a Phillips® screwdriver, loosen the screw on the battery compartment door located on the bottom of the unit.


Remove the battery compartment door. Insert four (4) AA batteries, making sure to align the "+" and "-" signs.

Loosen the battery compartment door and screw.

TO ENSURE PROPER FUNCTION:

- Do not mix old and new batteries.
- Do not mix alkaline, standard or rechargeable batteries.
- Battery installation should be done by adult.
- Non-rechargeable batteries are not to be recharged.
- Rechargeable batteries are to be removed from the toy before being charged (if removable).
- Rechargeable batteries are only to be charged under adult supervision.
- Only batteries of the same or equivalent type as recommended are to be used.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are not to be short-circuited.

Replace with new batteries at the first sign of erratic operation.





TIGER RECOMMENDS
DURACELL

OBJECT OF THE GAME

Collect the most Pokémon character disks and you win!

LET'S GET READY



1. Turn over the unit, squeeze the latch and lift the door on the character disk storage space. Remove the character disks and close the door.




Place unit face up on the table.

CAUTION: Do not press down on the unit while it is upside down or you may break the launch arms.


2. Divide the character disks evenly between both players. Choose a character disk for your top. The base of your top should be the same color as the launch arm and flipper control knobs that you are using.
3. Remove the clear plastic cover from the top. To do this, turn it counter-clockwise until it stops, then use the ribs to lift.




4. Place the character disk in the top so that the Pokémon is facing you.




5. Replace the clear plastic cover by aligning the tabs on the cover between the slots in the base. Turn the lid clockwise until the tabs are locked into the slots.




6. Raise the LAUNCH ARM by pressing the LAUNCH BUTTON. Your LAUNCH ARM should be the same color as your top.




7. Insert the point of the top into the LAUNCH BASE, making sure that it is centered.




8. Hold the top in place and gently lower the LAUNCH ARM so that it catches the knob on the cover of the top.




9. Press the WIND UP button.




10. At the same time, both players press their LAUNCH buttons. The tops will be launched into the arena and the challenge begins.



11. Each player has a set of FLIPPERS to knock the tops back into the center of the arena. You use the FLIPPER CONTROL KNOBS that are the same color as your top. Turn the FLIPPER CONTROL KNOBS left and right to move the FLIPPERS.



12. The tops will battle by bouncing off the walls of the arena, the flippers and each other. The last top standing is the winner of the round.



13. At the end of a battle, the player with the losing top removes the character disk, hands it to the winner and inserts a new character disk.

14. The game is over when one player has all the Pokémon character disks.

15. When you are done playing, replace the Pokémon character disks in the storage unit on the bottom of the unit.

WARNING: DO NOT STORE POKÉMON CHARACTER DISKS ON TOP OF THE BATTLE ARENA. THEY MAY SLIDE INTO THE BASE. IF THIS IS HAPPENS, THERE IS NO WAY TO RETRIEVE THEM.

If you want to add to your collection of Pokémon characters, the disks for Tiger's Pokémon Cyclone 2 fit the tops in your Pokémon Challenge game. They are sold separately.

DEFECT OR DAMAGE

If a part of your game is damaged or something has been left out, DO NOT RETURN THE GAME TO THE STORE. The store doesn't have replacement parts. Instead, write to us at:

Tiger Repair Department
1000 N. Butterfield Road, Unit 1023
Vernon Hills, IL 60061, U.S.A.

In your note, mention the name of your game, your game's model number, and tell us briefly what the problem is. Also include sales slip, date, place of purchase and price paid. We will do our best to help.

90-DAY LIMITED WARRANTY

Tiger Electronics Ltd. (TIGER) warrants to the original consumer purchaser of this product that the product will be free from defects in materials or workmanship for 90 days from the date of original purchase. This warranty does not cover damages resulting from accident, negligence, improper service or use or other causes not arising out of defects in materials or workmanship.

During this 90-day warranty period, the product will either be repaired or replaced (at TIGER'S option) without charge to the purchaser, when returned with proof of the date of purchase to either the dealer or to TIGER.

Product returned to TIGER without proof of the date of purchase or after the 90-day warranty period has expired, but prior to one year from the original date of purchase, will be repaired or replaced (at TIGER'S option) for a service fee of US\$11.00. Payments must be by check or money order payable to Tiger Electronics Ltd.

THE FOREGOING STATES THE PURCHASER'S SOLE AND EXCLUSIVE REMEDY FOR ANY BREACH OF WARRANTY WITH RESPECT TO THE PRODUCT.

All product returned must be shipped prepaid and insured for loss or damage to:

Tiger Repair Department
1000 N. Butterfield Road, Unit 1023
Vernon Hills, IL 60061, U.S.A.

The product should be carefully packed in the original box or other packing materials sufficient to avoid damage during shipment. Include a complete written description of the defect, a check if product is beyond the 90-day warranty period, and your printed name, address and telephone number.

THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES AND NO OTHER REPRESENTATIONS OR CLAIMS OF ANY NATURE SHALL BE BINDING ON OR OBLIGATE TIGER IN ANY WAY. ANY IMPLIED WARRANTIES APPLICABLE TO THIS PRODUCT, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO THE NINETY (90) DAY PERIOD DESCRIBED ABOVE. IN NO EVENT WILL TIGER BE LIABLE FOR ANY SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES RESULTING FROM POSSESSION, USE, OR MALFUNCTION OF THIS TIGER PRODUCT.

Some states do not allow limitations as to how long an implied warranty lasts and/or exclusions or limitations of incidental or consequential damages, so the above limitations and/or exclusions of liability may not apply to you. This warranty gives you specific rights, and you may also have other rights which vary from state to state.



© 1995, 1996 & 1998 Nintendo, CREATURES, GAME FREAK.
TM & ® are trademarks of Nintendo.
© 1999 Nintendo.

TIGER
ELECTRONICS, LTD.



For more information about Tiger Electronics, our products and special promotions, please visit our web site at: www.tigertoys.com.

®, TM, & © 1999 Tiger Electronics, Ltd. All Rights Reserved.
980 Woodlands Parkway, Vernon Hills, Illinois 60061, U.S.A.

®, TM, & © 1999 Tiger Electronics UK Ltd. All Rights Reserved.
Belvedere House, Victoria Avenue, Harrogate,
North Yorkshire HG1 1EL, England.

PRINTED IN CHINA

89104000