


FLYING SUBMARINE (S.H.A.R.C.) INSTRUCTIONS




Fit action levers into slots in hull as shown. Slide them all the way to the back. Place pieces of styrofoam into lower hull as shown. (ILL. 1)




3 Snap cannons into upper hull with posts facing rear. (ILL. 3)




5 To operate cannons, slide action levers. Attach exhaust to hulls as shown. Place bottom pin of rudder into hole on back of hull as 6 Snap engine cover over engine with handle toward rear. shown. Snap top pin into top hole. Repeat with other rudder. (ILL. 5)



Peel and apply labels #21 and #22 as shown. Place T-shaped styrofoam into opening in cockpit as shown. Fit cockpit into place. Place engine intakes into position. Put lower hull aside. (ILL. 2)



4 Snap cannon doors onto pins on cannons and close doors. First hook front tab of upper hull under front of white lower hull. Then snap back and side tabs into position. (ILL. 4)




Press canopy posts with your thumbs into hinges in hull. (ILL. 6)


DEEP SIX

ONE-WAY

TUBING ILL. 8



7 Press torpedo halves together. Press cap over front and snap ring over back of torpedo. Repeat with other torpedo. Press torpedo or G.I. Joe figure onto peg on bottom of S.H.A.R.C. The S.H.A.R.C. floats in water. (Figure not included.) (ILL. 7)



8 Attach one-way valve and connector to bellows as shown. Thread string through hole in valve and bellows and tie it. Attach plastic tubing to connector and to air duct in back of diver's suit. Pump bellows. Diver surfaces or submerges in water. Take valve off. Turn it around. Plug other end into bellows to make him g in the opposite direction. (ILL. 8) "DEEP SIX" can ride in cockpit as

